


# BIJUR LUBRICATION & FITTING CHART AUBURN 8-101, 8-105

PLACES  
LUBRICATED



SPRING HINGE 3

F.A. STEERING KNUCKLE UPPER & LOWER BEARING-STEERING KNUCKLE THRUST BEARING 6

CLUTCH RELEASE BEARING 1

REAR SPRING HINGE 2

REAR SPRING SHACKLE 4

TOTAL 16

Original Drip Plug	Replacement meter-Unit	Qty
LSA-0	CSA-0	1
LSA-1	CSA-1	3
LSA-2	CSA-2	2
LTA-0	CTA-0	3

ALL TUBING 5/32 O.D. x .025 WALL ANNEALED COPPER OR BRASS UNLESS OTHERWISE SPECIFIED.